



---

Fine tune the potentiometer adjustment at this end to equalize the difference between the ends. The potentiometer gear segment should maintain engagement with the drive gear throughout full actuator travel. If this is not the case, either the travel is exceeding 90 degrees or the pot is mounted backwards.